

# maku-DieTool® options









# Fully automatic deckling adjustment Semi-automatic deckling adjustment Lower lip adjustment



Fully automatic deckling adjustment internal/external



Semi-automatic deckling adjustment



Lower lip adjustment

#### Fully automatic deckling adjustment internal/external

In combination with the **maku-DieTool**\*, the internal and external deckling of a flat die can be automatically adjusted to different die widths. At the push of a button, the **maku-Die-Tool**\* adjusts the die bolts affected by the deckling, which are an essential part of the deckling. The sequence enables an optimized retraction and extension of the deckling as well as a blade change, due to different blade thicknesses.

### ▶ Semi-automatic deckling adjustment

With this simplified version of the deckling adjustment, the **maku-DieTool**\* is only responsible for opening and closing the die bolts affected by the deckling during a blade shift or a blade change. The blade shift is then performed manually.

## Lower lip adjustment

The lower lip adjustment enables an adjustment of the lower lip with a travel of max. 20 mm during production. Due to a special gear and motor configuration, we have the possibility to achieve an adjustment even with high acting torques. The motor brake locks the lower lip.

